

# Wide variety of stitch patterns



80 Sewing Patterns

HZL-70HW-B

## **Sew Comfortably!**



The needle threader easily threads the needle and allows you to start sewing quickly.



The color of the Start / Stop button indicates the status of the machine.



winding condition



HZL-H series can sew a lock stitch at the beginning and end of sewing. There are two types of lock stitch, reverse stitch and reinforcement stitch.



There are 6 types of stitch patterns, from which you can choose one by directly pushing the pattern button.

### Sew Firm!



Press the button to change up/down position of needle instantly. Also you can change needle stop position and can even sew a half stitch.



HZL-H series sews the buttonhole automatically according to the size of the button.





#### Accessories



A:Standard Presser Foot B:Zipper Foot C:Decorate Stitch Foot D:Overcasting Foot E:Blind Stitch Foot F:Button Sewing Foot G:Buttonhole Foot H:Seam Ripper/ Brush I:Screwdriver (S) J:Screwdriver(L-shape) K:Auxiliary Spool Pin L:Bobbin (3x) M:Quilt Guide N:Spool Cap(Large) O:Spool Cap(Small) P:Spool Pin Felt Q:Pack of Needles(3x)

# **Easy to Use!**



You can change the size of stitch patterns as well as the needle positions







Hard Case

## Other Features

- Free Arm Drop-in Bobbin
- Drop Feed
- Easy to Start Sewing Thick Fabrics
- Button Sewing

